

# BECCA® Options & Accessories

For  
Solvent Saver™  
Recyclers

*The  
Professionals  
Choice*

## VACUUM ASSIST SYSTEM

For SOLVENT SAVER™ SC & HC Models.

The Vacuum Assist system was designed to reduce the atmospheric pressure in the boiler for three functions:

- Increase the differential between the Auto Ignition Temperature and the boiling point of a solvent. This reduces the potential hazard during the distillation process.
- Increase the capability of the Recycler to handle solvents with higher boiling points.
  - Normal Recycler Capability 390 °F
  - Vacuum Assist System Capability 430 °F
- Improve performance (speed) of the Recycler— from 10–30%



Vacuum Assist can be used on any Recycler package. The compact design allows the system to be placed within the cabinet.  
Note: Some systems will require a pump transfer kit to move the solvent from the Vacuum Assist tank to another container such as a drum or another clean solvent tank. Contact BECCA for the selection requirements for your system

## BECCA Protect™ Film

**NEXT™ 10, 30,  
70 & 80 Models**



Before  
Removal

New  
Application of  
BECCA  
Protect™



# Recycler/Dual Spray Gun Cleaner Valve Kit

For SOLVENT SAVER™ SC & HC Models

This system provides the capability for a Recycler to handle **two** Spray Gun Cleaners. The function is quite simple. The valve package allows an operator to select between an “A” or “B” Spray Gun Cleaner to unload the “Used” solvent to the recycler.



Any of BECCA's Spray Gun Cleaners can be utilized for the Recycler/Dual Spray Gun Cleaner Valve Kit.

## 5 Gallon Cans or 10 Gallon Tanks

NEXT™ 10 30, 70 & 80 Models

The **5 gal Cans** are standard solvent containers and come equipped with a pour spout.



NEXT™ 70 & 80

The **10 gal Tanks** are designed for the most demanding operations. Performance features:

- Stainless Steel Construction
- Sight Glass
- Direct Connection



## Tank Transfer Pump Kit

For SOLVENT SAVER™ SC & HC Models

Some Recycler Systems require the transfer of solvents to and from the unit. We have Transfer Kits available to handle any situation:

- ONE WAY Pump Transfer Kit—provides a pump and valve system to control the loading of the solvent boiler or to unload the “clean” solvent tank (including Vacuum Assist) to another container.
- TWO WAY Pump Transfer Kit—provides two pumps and valves to handle both loading and unloading of the Recycler.



The shows a “Clean” solvent pump system on the back of a recycler ready to move solvent to another container.



### BECCA Inc.

2010 Cobb International Blvd  
Suite H  
Kennesaw, GA 30152  
T 800. 655.5649  
F 800. 655. 5684  
www.beccainc.com  
sales@beccainc.com

For More Information go  
to [www.beccainc.com](http://www.beccainc.com)