

# FLASH DRY

RAPID DRYING SYSTEM

4B AIR TECHNOLOGY™  
WATERBORNE  SOLVENT 



Pays For Itself In 30 Days!

Cuts Dry Times 20-50%

- 1 More Job Per Day!
- 10 Micron Filtration
- No Compressed Air



## WHAT IS 4B AIR TECHNOLOGY?

- **Dynamic Air Movement:** *Non-directional Air Flow* resulting in more effective drying.
- **Directional Air Control:** Fixed position nozzles adjustable to target sizes
- **Dehydrating Paint:** Quickly and effectively removes solvents
- **Dries Fast:** Our 4B AIR TECHNOLOGY™ Delivers Supreme Performance!



Innovation For Waste Minimization

# FLASH DRY™ RAPID DRYING SYSTEM

**4B AIR TECHNOLOGY™**  
WATERBORNE  SOLVENT 

The **FLASH DRY™** system with **4B AIR TECHNOLOGY™** by BECCA was designed to provide a highly effective for both Waterborne and Solvent drying system while meeting the price the average shop can afford.

## THE SYSTEM WILL PROVIDE:

- **SPEED** - Rapid Drying by the Powerful Directed Nozzle System
- **EASY TO OPERATE** - One Button Start
- **ADJUSTABILITY** - Once the System has been set-up there is no need for Adjustments
- **LOW COST TO USE** - Avg. cost is approximately 30 cents /Day
- **VALUE PRICED** - Flash Dry System has a low purchase cost and can also reduce your need to upgrade your Compressor

## STANDARD UNIT FEATURES:

- **HIGH STATIC BLOWER** - Generates a Powerful amount of Air
- **2 HP MOTOR** - All the Power necessary to Drive the High Static Blower
- **ON/OFF MOTOR STARTER** - Easy to Start & Stop
- **ERECTOR SET CONSTRUCTION** - Easy to Install
- **FLEXIBLE DESIGN** - Extra Components have been provided to accommodate different booth lengths (Up to 28') & entry locations
- **TEMPERED/FILTERED AIR** - Intake Air is Clean Filtered and Tempered (Heated Booth) Spray Booth Air, not Dusty Shop or Compressed Air.

## OPTIONAL UPGRADES:

- **PAINTED WHITE** - Powder Coat the Nozzle Tubes & Damper in the Booth Part# 870100 - \$500\*
- **PUFF SWITCH** - Explosion Proof switch allows turning the system On/Off in-side the Spray Booth (This option replaces On/Off (Controls Outside the Spray Booth. Must be purchased with Order - Retrofit is a Higher Price ). Part# 870300 - \$160\*
- **MOTOR VOLTAGES & 1PHASE** - BECCA has 208—240 Volt 3 Phase standard. 480V & 1 Phase Electrical is available (Must be Specified upon Order - This may extend the Lead Time for Delivery). \*Call for Part# & Pricing



## Product Specifications:

**Voltage:**(Std System) 208-240 Volt AC, 3 P h a s e , 5.8 Amp(Requires 15 Amp Circuit)

## Dimensions:

The basic package was designed for any Spray Booth, CTOF, & Prep Stations 24' - 28'L x 14'W (Downdraft, Semi-downdraft or cross-draft)

## Includes:

Motor & Blower, Motor Starter, Galvanized Intake & Supply Ductwork w/ Nozzles, Tech Screws, Aluminized Tape, & Decals

## Note:

Extra Duct is provided to handle various entry points & Lengths

## Not Included:

Install & Electrical Technician

**Shipping:** Via Freight



2010 Cobb International Blvd, Suite H  
Kennesaw, GA 30152  
Phone 800.655.5649 Fax 800.655.5684  
Internet: [www.beccainc.com](http://www.beccainc.com)

