



# S800A

## Deluxe Automatic/Manual Solvent Spray Gun Cleaning Workstation

- **POWERCLEAN** •  
Protects Air Passageways
- **AUTOMATIC WASH BASIN** •  
Hands-Free Operation
- **PULSATING FLUID POWER CLEANING** •  
Flushes Away Contamination

The BECCA S800A Automatic Spray Gun Cleaner Workstation is designed to meet the challenges of getting solvent spray guns clean quickly...

- Cleans all of the fluid passageways
- Protects air passageways to prevent contamination and corrosion

Check out our brief Training Videos at  
[www.beccainc.com](http://www.beccainc.com)



# S800A

Deluxe Automatic/Manual

 Solvent Spray Gun Cleaning Workstation



## STANDARD UNIT FEATURES:

**Stainless Steel Basin w/ Cover** – Painter Friendly

**Automatic Hands-Free Cycle** – Reduces Operator's Time

**Powerpistol™** – Quick & powerful Spray Gun Cleaning

**Powerclean™** – Compressed Air Connection Protecting Air Passageways

**Pulsating Fluid** – Powerful Cleaning Efficiency

**Used/Clean Fluid Control** – Superior Cleaning and 50% Solvent Savings

**Flow Brush/Spigot** – Improved Cleaning of dried material

**Ultra Light™ QD's** – High Flow light weight Corrosion Resistant

**Red Powder Coated Finish** – Long Maintenance Life

**Input Air Filter/Regulator** – Proper System Air Control

**Clarifier Recycling System w/ Air Bubbler** – 3 Containers and Dual Filter System

**NESHAP and NFPA 33 Compliant** – Meets Requirements

## Product Specifications:

Dimensions:

Overall:

57" H x 26" W x 26" D

1447 mm x 660 mm x 660 mm

Working: (Stainless Steel Basin)

14" H x 20" W x 12" D

356 mm x 508 mm x 305 mm

Weight: 270 lbs (123kg)

Shipping: Via Freight

## Optional Upgrades:

**Solventwash™ Cartridge Filtration** - Less Maintenance & Improved Productivity with a Two Stage Filtration System (75 & 25 Micron Filters)

**Fluid Reservoir** – 5 Gallon Steel Can or 10 Gallon Stainless Steel Tank to hold Clean and/or Used Solvent Supply

**Dual PowerClean Kit** - Second Spray Gun Connection in the Wash Basin

**Turbo™ Pressure Pot & Fluid Line Cleaner System**

**BECCA Protect Film** – Maintenance Film Coating

**Carbon Absorption Exhaust System**



**POWERPISTOL™** - Pulsating Fluid. Powerful cleaning for the Fluid Passageways



**STAINLESS STEEL AUTOMATIC WASH BASIN** - Maximize Operator Productivity



**POWERCLEAN™** - Supply's compressed air to the Spray Gun during the cleaning process, protecting the air passageways.

