



BECCA[®] Solvent Saver[™]

Solvent Recycler
SS17.5 (17.5 Gal)

*The
Professionals
Choice*

SOLVENT SAVER[™]

Benefits

- Reduces your Solvent Purchases up to 95%
- Reduces Your Hazardous Waste Generation up to 95%

Features

- Listed to Class I Division 1 Requirements
- Listed to UL2208 at the Highest Level
- Able to process Conventional, Alternative & Waterborne Solvents
- Fully Automated Cycle
- 1 Year Warranty
- **BECCA Care[™]** - Local sales, installation, training and service



Shown w/
Optional
Transfer Kit

Ask us about our **FREE** test of your waste solvent for evaluation!



CSA Listed per UL2208 Std for Solvent
Distillation Units &
for Class I Div 1 Requirements

"Innovation for Waste Minimization"



BECCA®

It's all about improving your productivity, finishing quality, & saving money.

In today's environment, industrial operations know the meaning of efficiency, reduced cycle time and variable cost reduction.

BECCA continues to redefine what a Solvent Recycler supplier should do for its customers:

Help Customers Succeed

Deliver Quality Products

Bring the Latest in Technology

Provide the Best Service

Caution! - Do not use with products containing Nitrocellulose

Product Specifications

Boiler Capacity: 17.5 Gal (66 liters)
Working Temp: 104–450°F (40–232°C)
Heating : Direct
Cooling : Air–Fan
Recovery Rate: 95–100%
Electrical: 220–240 Volt 1 Phase
Amperage: 13.5 Amps
Dimensions: 62”H x 24”W x 37” D
Construction: Class I Div 1 Explosion Proof, Teflon Coated Aluminum Tank & Lid, Ultra Powder Coat Finish, One Touch Controls
Operating Time: 3 – 7 Hours
Weight: 400 lbs.
Shipping: Freight



Available Options

Recycler Bags – These bags are specially designed for performance. The Bag liner contains the left-behind residues, is easily and cleanly removed.

Protect™ Film – This is a maintenance film that makes clean-up simple and easy...just peel away the film and apply a new coating

Transfer Kit – Drum to Recycler – Pump Kit designed to allow transfer of solvent from a 55 Gallon Drum to the BECCA Solvent Saver Recycler. Includes St/St Braided lines with wand for long durable use

Accel-Cool™ System – This add on system uses compressed air through a Transvector to accelerate the cool down . This would mean less than 1-2 hour to the next process.

Vacuum Assist System— Lowers atmospheric pressure in the boiler for:

- Increase the differential between the Auto Ignition Temperature and the boiling point of a solvent., reducing the hazard.
- Increases the capability of the Recycler to handle solvents with high boiling points.
- Improves the speed of the Recycler from 10 – 30%.

Stainless Steel Condenser – This upgrades the condenser from Copper to Stainless Steel – necessary for some applications

“Anti-Foaming” Grill – This is perforated metal designed to break up bubble formation from certain waste solvent combinations

“Anti-Foaming” Additive - This additive will assist breaking up bubble formation from certain waste solvent combinations



2010 Cobb International Blvd
Suite H
Kennesaw, GA 30152
T 800. 655.5649
F 800. 655. 5684
www.beccainc.com
sales@beccainc.com

For More Information go to www.beccainc.com