



INSTALLATION REVIEW QUESTIONS

1. To assist with the Installation, we would like to know the type of Spray Booth. (A few Pics would be helpful)

Type of Spray Booth: Mfg & Model _____

Booth Length: _____ Ft

2. There must be at least 20” clear space above the Spray Booth in order to install the Blower Package. (If not alternatives can be considered – take pics and review with BECCA)

Clear space above Spray Booth: _____ Ft (Need 20”+)

3. It is preferred to enter the front or rear of the Spray Booth with the 4” Blower Tubes. (Most prefer the rear as long as there is access)

Customer preference (X) : Front _____ Rear _____

Is there clearance? Front _____ Ft Rear _____ Ft (Need 2’ +)

- 3b. If the customer does not want to go through the front and there is not enough clearance in the back of the booth (2 Ft), we can go in through the Hip Panels. (Note: This will leave a larger area before the first Blower Holes are positioned - because the damper needs some space before the first Blower Hole)

Preference to go through the Hip Panels(X) : Yes _____ No _____

4. If the paint requires drying between coats we recommend the “Puff Switch” for ease and reduced contamination.

Is the customer selecting a “Puff Switch” (X) : Yes _____ No _____

5. What is the Electric:

Phase (X) : Single _____ or Three Phase _____

Voltage (X) : 208-230 _____ 440-480 _____