



# SOLVENT SAVER™ RECYCLER

## Solvent Recycler SS55 (55 Gal)

*The  
Professionals  
Choice*

### SOLVENT SAVER™

#### Benefits

- Reduces your Solvent Purchases up to 95%
- Reduces Your Hazardous Waste Generation up to 95%

#### Features

- Listed to Class I Division 1 Requirements
- Listed to UL2208 at the Highest Level
- Able to process Conventional, Alternative & Waterborne Solvents
- Fully Automated Cycle
- 1 Year Warranty
- **BECCA Care™** - Local sales, installation, training and service



Ask us about our FREE test of your waste solvent for evaluation!



CSA Listed per UL2208 Std for Solvent  
Distillation Units &  
for Class I Div 1 Requirements

*"Innovation for Waste Minimization"*



# BECCA®

It's all about improving  
your productivity, finishing  
quality, & saving money.

In today's environment, industrial operations know the meaning of efficiency, reduced cycle time and variable cost reduction. BECCA continues to redefine what a Solvent Recycler supplier should do for its customers:

**Help Customers Succeed**

**Deliver Quality Products**

**Bring the Latest in Technology**

**Provide the Best Service**

**Caution!** - Do not use with products  
containing Nitrocellulose

## Product Specifications

**Boiler Capacity:** 55 Gal (208l)

**Working Temp:** 104–450 °F (40–232 °C)

**Heating :** Direct

**Cooling :** Air–Fan

**Recovery Rate:** 95–100%

**Electrical:** 220 Volt 1 Phase

**Amperage:** 50 Amps

**Dimensions:** 90”H x 42”W x 60” D  
(Note: 112” H w/ Winch System)

**Construction:** Class I Div 1 Explosion Proof,  
Teflon Coated Aluminum Tank & Lid,  
Ultra Powder Coat Finish, One Touch Controls

**Operating Time:** 6 – 8 Hours

**Weight:** 1115 lbs.

**Shipping:** Freight



## Available Options

**Recycler Bags** – These bags are specially designed for performance. The Bag liner contains the left-behind residues, is easily and cleanly removed.

**Protect™ Film** – This is a maintenance film that makes clean-up simple and easy...just peel away the film and apply a new coating

**Transfer Kit – Drum to Recycler** – Pump Kit designed to allow transfer of solvent from a 55 Gallon Drum to the BECCA Solvent Saver Recycler.

Includes St/St Braided lines with wand for long durable use

**Accel-Cool™ System** – This add on system uses compressed air through a Transvector to accelerate the cool down . This would mean less than 1-2 hour to the next process.

**Vacuum Assist System**— Lowers atmospheric pressure in the boiler for:

- Increase the differential between the Auto Ignition Temperature and the boiling point of a solvent., reducing the hazard.
- Increases the capability of the Recycler to handle solvents with high boiling points.
- Improves the speed of the Recycler from 10 – 30%.

**Stainless Steel Condenser** – This upgrades the condenser from Copper to Stainless Steel – necessary for some applications

**“Anti-Foaming” Grill** – This is perforated metal designed to break up bubble formation from certain waste solvent combinations

**“Anti-Foaming” Additive** - This additive will assist breaking up bubble formation from certain waste solvent combinations



2010 Cobb International Blvd  
Suite H  
Kennesaw, GA 30152  
T 800. 655.5649  
F 800. 655. 5684  
www.beccainc.com  
sales@beccainc.com

For More Information go  
to [www.beccainc.com](http://www.beccainc.com)